











Machine	Explode	Code	Description
GL186 - Polar werkbank koeling 1 deur en 2 laden	1	AD301	Down Hinge Right
GL186 - Polar werkbank koeling 1 deur en 2 laden	3	AB346	Spring Hinge
GL186 - Polar werkbank koeling 1 deur en 2 laden	4		Front Panel Hinge Down
GL186 - Polar werkbank koeling 1 deur en 2 laden	5	AF734	Door Seal
GL186 - Polar werkbank koeling 1 deur en 2 laden	7		Door Right
GL186 - Polar werkbank koeling 1 deur en 2 laden	9	AB579	Lock & Key
GL186 - Polar werkbank koeling 1 deur en 2 laden	10		Front Panel Lock Hook
GL186 - Polar werkbank koeling 1 deur en 2 laden	11	AD303	Up Hinge Right
GL186 - Polar werkbank koeling 1 deur en 2 laden	12		Front Panel
GL186 - Polar werkbank koeling 1 deur en 2 laden	13	AD902	Look Hook for Door
GL186 - Polar werkbank koeling 1 deur en 2 laden	14		Thermostat Cover
GL186 - Polar werkbank koeling 1 deur en 2 laden	15		Front Panel Hinge Up
GL186 - Polar werkbank koeling 1 deur en 2 laden	16		Evaporator Cover Left
GL186 - Polar werkbank koeling 1 deur en 2 laden	18	AA639	Sensor Fixed Clip
GL186 - Polar werkbank koeling 1 deur en 2 laden	19	AB953	Probe Padding
GL186 - Polar werkbank koeling 1 deur en 2 laden	20		Air Flow Conduct Board Left
GL186 - Polar werkbank koeling 1 deur en 2 laden	21		Evaporator Fixed Board Front
GL186 - Polar werkbank koeling 1 deur en 2 laden	22		Fan Fixed Board
GL186 - Polar werkbank koeling 1 deur en 2 laden	23	AB339	Evaporator Fan
GL186 - Polar werkbank koeling 1 deur en 2 laden	24		Evaporator Water Pan
GL186 - Polar werkbank koeling 1 deur en 2 laden	25	AF736	Evaporator
GL186 - Polar werkbank koeling 1 deur en 2 laden	26		Evaporator Fixed Board Back
GL186 - Polar werkbank koeling 1 deur en 2 laden	27		Air Flow Conduct Right
GL186 - Polar werkbank koeling 1 deur en 2 laden	28		Evaporator Cover Right
GL186 - Polar werkbank koeling 1 deur en 2 laden	29		Unit Room Cover
GL186 - Polar werkbank koeling 1 deur en 2 laden	30		Plug
GL186 - Polar werkbank koeling 1 deur en 2 laden	31		Front Thermostat Support(old version)
GL186 - Polar werkbank koeling 1 deur en 2 laden	31		Front Thermostat Support(new version)
GL186 - Polar werkbank koeling 1 deur en 2 laden	31		Rear Thermostat Support
GL186 - Polar werkbank koeling 1 deur en 2 laden	32	AB363	Thermostat
GL186 - Polar werkbank koeling 1 deur en 2 laden	33	AB308	Main Switch
GL186 - Polar werkbank koeling 1 deur en 2 laden	34		Discharge Pipe
GL186 - Polar werkbank koeling 1 deur en 2 laden	35		Water Box
GL186 - Polar werkbank koeling 1 deur en 2 laden	36	AB295	Condenser
GL186 - Polar werkbank koeling 1 deur en 2 laden	37		Suction Pipe
GL186 - Polar werkbank koeling 1 deur en 2 laden	38	AB339	Condenser Fan
GL186 - Polar werkbank koeling 1 deur en 2 laden	39	AH015	Compressor(R134a)
GL186 - Polar werkbank koeling 1 deur en 2 laden	39	AG013	Compressor(R600a)
GL186 - Polar werkbank koeling 1 deur en 2 laden	42		Unit Board
GL186 - Polar werkbank koeling 1 deur en 2 laden	44		Body
GL186 - Polar werkbank koeling 1 deur en 2 laden	45		Feet
GL186 - Polar werkbank koeling 1 deur en 2 laden	46		Adjust Bolt
GL186 - Polar werkbank koeling 1 deur en 2 laden	47		Back Support Left
GL186 - Polar werkbank koeling 1 deur en 2 laden	48		Front Support Left
GL186 - Polar werkbank koeling 1 deur en 2 laden	49		Back Support Right

GL186 - Polar werkbank koeling 1 deur en 2 laden	50		Front Support Right
GL186 - Polar werkbank koeling 1 deur en 2 laden	51		Lamp(old version)
GL186 - Polar werkbank koeling 1 deur en 2 laden	51		LED Lamp(change from 2018.12)
GL186 - Polar werkbank koeling 1 deur en 2 laden	52		Guide Right
GL186 - Polar werkbank koeling 1 deur en 2 laden	53		Shelf
GL186 - Polar werkbank koeling 1 deur en 2 laden	54		Guide Left
GL186 - Polar werkbank koeling 1 deur en 2 laden	55		Small Plastic Cap
GL186 - Polar werkbank koeling 1 deur en 2 laden	56		Bridge
GL186 - Polar werkbank koeling 1 deur en 2 laden	57		Screw
GL186 - Polar werkbank koeling 1 deur en 2 laden	58		Washer
GL186 - Polar werkbank koeling 1 deur en 2 laden	59	AF743	Drawer Gasket
GL186 - Polar werkbank koeling 1 deur en 2 laden	60		Guide Right
GL186 - Polar werkbank koeling 1 deur en 2 laden	61		Down Drawer Panel
GL186 - Polar werkbank koeling 1 deur en 2 laden	62		Guide Left
GL186 - Polar werkbank koeling 1 deur en 2 laden	63		Drawer Body
GL186 - Polar werkbank koeling 1 deur en 2 laden	64		Up Drawer Panel
GL186 - Polar werkbank koeling 1 deur en 2 laden	65		Front Panel Lock & Key
GL186 - Polar werkbank koeling 1 deur en 2 laden	66	AJ506	Drawer Lock & Key
GL186 - Polar werkbank koeling 1 deur en 2 laden	67		Bridge
GL186 - Polar werkbank koeling 1 deur en 2 laden	68	AE827	Door Bushing
GL186 - Polar werkbank koeling 1 deur en 2 laden	69	AG960	Filter Drier
GL186 - Polar werkbank koeling 1 deur en 2 laden	70	AC614	Sensor
GL186 - Polar werkbank koeling 1 deur en 2 laden	71	AJ158	LED Transformer(from 2018.12)
GL186 - Polar werkbank koeling 1 deur en 2 laden	N/A	AJ161	Electrics for Compressor HDL140A
GL186 - Polar werkbank koeling 1 deur en 2 laden	N/A		Look Hook for Drawer